

# AMS : COMMON ISSUES/SOLUTIONS

"My Display won't paint."

Verify G, H, and I are filled out correctly

Verify correct operation is selected

Verify there is only one tab on the documentation page

"How do I change my turn on/off times?"

Menu > GreenStar > Section or Swath

"Which way do I move my times?"

On a GS3 there is a "?" in the center of the screen. Hit the "?" and it will instruct you on how to adjust. On a GS2 see the second page.

"My painting starts late in the pass."

The seconds for the SCV detent are set too high. Set the timing only as high as to allow the implement to fully lower into the ground.

"How do I adjust my Section Control timing?"

Product application starts too soon : **Decrease** turn on time

Product application starts too late : **Increase** turn on time

Product application stops too soon : **Decrease** turn off time

Product application stops too late : **Increase** turn off time

"I'm experiencing wide narrow gaps."

Calibrate the TCM

Verify that it is not implement drift by measuring pass to pass at the drawbar

"Client farm field is grayed out"

Pick up your implement

Make sure you are not recording an autotrac line

Make sure the master switch is off

***Always verify that your AMS components are updated to the latest software.***

