


## GREENSTAR: COMBINE OFFSETS



- Distance from center-line of machine to GPS receiver.

  NOTE: This value is typically left at 0.0 inches.
- B Distance from non-steering (front) axle to GPS receiver.
- Distance from non-steering (front) axle to header connection point.
- Vertical distance from GPS receiver to ground.



## GREENSTAR: HEADER OFFSETS



**A & D** Measurements 'A' & 'D' are not required for headers, and can be left at 0.0.

Distance from connection point to harvesting point.

CORN HEADS: Harvesting Point = Front of Stalk Rolls

PLATFORM HEADS: Harvesting Point = Front of Cutter Bar

Lateral distance from center of combine to center of header.

NOTE: This value is typically left at 0.0 inches, unless using an offset header.